# LOSETTEC 3DR ULTRA MULTI-LINE LASER



INSTRUCTION MANUAL

# SAFETY

Read the following safety instructions before attempting to operate this product.

Keep these instructions in a safe place or store in the carry case for future reference.

# SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE.



WARNING: Read and understand all instructions.

- Use the laser only with the specifically designated batteries.
- Store the laser out of reach of children and other untrained persons. Lasers are dangerous in the hands of untrained users.
- Use only accessories that are recommended for your model.

- Tool service must be performed only by qualified repair personnel. Repairs, service or maintenance performed by unqualified personnel will void the warranty. Only approved and authorised service technicians can carry out warranty repairs.
- Do not use optical tools such as a telescope or transit to view the laser beam. Serious eye injury could result.
- Do not place the laser in a position which may cause anyone to intentionally or unintentionally stare into the laser beam. Serious eye injury could result.
- Do not position the laser near a reflective surface which may reflect the laser beam toward anyone's eyes. Serious eye injury could result.
- · Do not use optical tools to view the laser beam.
- Do not set up the tool at a position where the laser beam can cross any person at head height.

# SAFETY (continued)

- · Do not let children come in contact with the laser.
- Turn the laser off when it is not in use. Leaving the laser on increases the risk of staring into the laser beam.
- Do not operate the laser around children or allow children to operate the laser. Serious eye injury may result.
- · Do not remove or deface warning labels.
- Position the laser securely on a level surface.
   Damage to the laser or serious injury could result if the laser falls.



# WARNING: DO NOT DISASSEMBLE THE LASER.

There are no user serviceable parts inside. Disassembling the laser will void all warranties on the product. Do not modify the product in any way. Modifying the tool may result in hazardous laser radiation exposure.




# CAUTION: Class 2 Laser Product


- Never look into the laser beam directly and intentionally.
- Do not use optical tools to view the laser beam.
- Do not set up the tool at a position where the laser beam can cross any person at head height.
- · Do not let children come in contact with the laser.

# ITEM CHECKLIST


Please ensure the following items are included with your laser level. If anything is missing please contact your retailer.




# LASER OVERVIEW: FRONT



# LASER OVERVIEW: CONTROL PANEL



# **DETECTOR OVERVIEW: FRONT**




# **USING YOUR LASER**

## **POWER SUPPLY**

- The instrument is supplied with two li-ion battery packs as its power source.
- The instrument is also supplied with four AA alkaline batteries and has the ability to run using mains power as an alternative power source.
- The battery life is displayed via the battery status indicator lights on the control panel.

### Inserting & removing the li-ion battery pack

- · Open the battery cover door.
- Insert the li-ion battery pack according to polarity and close the battery cover door.




# Charging the li-ion battery pack (via the mains power / charging port)

- Insert the mains power adaptor / charger into the mains power / charging port on the back of the instrument.
- · Plug the charger into a power source.
- Progress will be shown by the battery status indicator lights displayed on the control panel as below:
  - \*\* Red (flashing) = Battery is charging
- Red (constant) = Battery is charged
- The instrument can operate while the battery is charging however charging time will dramatically increase.



# Charging the li-ion battery pack (via the charging adaptor)

- Insert the mains power adaptor / charger into the charging adaptor. Connect the li-ion battery onto the charging adaptor. Plug the charger into a power source.
- Progress will be shown by the power indicator display on the charging adaptor as below:
  - Red (flashing) = Charger and battery are not connected.
  - Red (constant) = Battery is charging
- Green (constant) = Battery is charged
- Charging time is approximately 3-4 hours for a depleted battery.





#### Mains power operation

- Insert the mains power adaptor / charger into the mains power port.
- Plug the mains power adaptor / charger into a power source.
- The instrument will operate without a battery inserted.

#### Inserting or replacing the alkaline batteries

- Insert the alkaline batteries into the battery tray according to polarity.
- Open the battery cover door, insert the battery tray and close the battery door.





#### **SET UP**

- Select a place as close as practical to the work site. Ensure the location is clear of traffic.
- Place the laser on a level surface such as a bench or mount.
- To mount the instrument onto the supplied multipurpose mount, follow the instructions on page 16

### **OPERATION**

#### Powering on (self levelling)

- To turn the instrument on, slide the power / locking switch to the "unlocked / on" position.
   Self levelling will commence and the horizontal beam will activate.
- Press the *line mode* button on the control panel to cycle through the active beams.

 If the instrument is outside the self levelling range the instrument will not level causing the laser beam to flash on and off repeatedly. If this occurs, reposition the instrument onto a level surface until the instrument can level off.

### Powering off


 To turn the instrument on, slide the power / locking switch to the "locked / off" position.




Always slide the *power / locking switch* to the "locked / off" position when transporting the instrument or moving around the job site.

#### Tilt lock function (manual mode)

- Ensure the power / locking switch is in the "locked / off" position.
- Press and hold the *line mode* button for 3 seconds. The horizontal line will activate.
- Press the *line mode* button on the control panel to cycle through the active beams.
- The instrument can now be tilted to the desired angle.
- To turn off the beams, press the line mode button until all beams are off.
- When in tilt lock function (manual mode) the instrument will **not** self level and correct for vibrations and/or disturbances.






#### USING THE DETECTOR


- Press and hold the power button for 3 seconds to enter into pulse mode. The LED pulse mode indicator will illuminate to show pulse mode is active.
- Switch the detector on by pressing the power button. The speaker will beep indicating the instrument is operating.
- · Move the detector into the path of the laser beam.
- Hold the detector upright for horizontal beams.
   Rotate the detector 90° for vertical beams.
- The LED direction indicators will indicate the position of the laser beam. The centre LED will indicate alignment with the beam.

Detector position for horizontal beams\*



<sup>\*</sup>Detector image shown is for illustrative purposes only. Actual model may vary.


# **MULTI-PURPOSE MOUNT OVERVIEW**



# USING THE MULTI-PURPOSE MOUNT

#### Mounting onto a magnetic surface

- Attach the instrument to the mount using the thumb screw
- Attach the mount to a metal surface, ensuring that the mount has a strong hold before releasing your hands.
- To adjust the height of the instrument, unlock the height adjustment knob. Rotate the height adjustment knob to raise or lower the instrument to the desired height. Retighten the height adjustment lock knob to secure in place.
- To rotate the instrument on the mount, loosen the mini thumb screw, position the instrument, and then re-tighten the thumb screw.



# **USING THE MULTI-PURPOSE MOUNT** (continued)

### Mounting via the clamp

- Attach the two mount pieces together via the magnetic backing.
- Attach the instrument to the mount using the thumb screw.
- Use the *clamp* to mount to a suspended ceiling track, ensuring that the mount has a strong hold before releasing your hands.
- To adjust the height of the instrument, unlock the height adjustment knob. Rotate the height adjustment knob to raise or lower the instrument to the desired height. Retighten the height adjustment lock knob to secure in place. Alternatively, slide the mount on the magnetic backing.
- To rotate the instrument on the mount, loosen the mini thumb screw, position the instrument, and then re-tighten the thumb screw.

#### Mounting via screw fixing points

- Attach the instrument to the mount using the thumb screw.
- Fix a screw into a secure surface and hook the mount over the screw. Ensuring that the mount has a strong hold before releasing your hands.
- To adjust the height of the instrument, unlock the height adjustment knob. Rotate the height adjustment knob to raise or lower the instrument to the desired height. Retighten the height adjustment lock knob to secure in place.
- To rotate the instrument on the mount, loosen the mini thumb screw, position the instrument, and then re-tighten the thumb screw.

# **USING THE MULTI-PURPOSE MOUNT** (continued)

### Mounting onto a tripod

- Attach the mount onto the tripod via the 5/8" or 1/4" thread.
- Attach the instrument to the mount using the thumb screw.
- To adjust the height of the instrument, unlock the height adjustment knob. Rotate the height adjustment knob to raise or lower the instrument to the desired height. Retighten the height adjustment lock knob to secure in place.
- To rotate the instrument on the mount, loosen the mini thumb screw, position the instrument, and then re-tighten the thumb screw.



The instrument can also be mounted onto a tripod without using the multi-purpose mount via the 1/4" thread or 5/8" x 11 thread on the base of the instrument.

# **TROUBLE SHOOTING**

Error	Cause & Solution			
Laser does not turn on	<ul> <li>Check the batteries. They may be in the wrong way or need replacing.</li> </ul>			
Laser does not turn on	<ul> <li>Check the battery compartment for signs of damage.</li> <li>Ensure they are clean and not bent.</li> </ul>			
Laser does not remain on for long periods of use.	<ul> <li>Check the batteries.</li> <li>Check the battery compartment for signs of damage. Ensure they are clean and not bent.</li> </ul>			
Laser does not level off	<ul> <li>Instrument may be outside its self levelling range. Adjust the instrument or tripod so it is level.</li> <li>Instrument may have impact damage.</li> </ul>			

# CARE AND MAINTENANCE

- This is a precision measuring instrument and should always be handled with care and transported within the carry case provided.
- Always slide the power / locking switch to the "locked / off" position when transporting the instrument or moving around the job site.
- Whenever possible, store the instrument in a dry, shady location.
- Calibration of the instrument is recommended: every six months, if ongoing accurate levelling is required, or an impact has occurred.

- The operator should check the accuracy of the instrument before precision levelling is attempted.
   Failure to do so may result in inaccurate measurements.
- Clean the instrument with a dry, soft cloth after use in dusty, damp or wet conditions before storing.
- Smudges and fingerprints may be removed with a damp tissue or a soft, lint-free cloth.

# WARRANTY

#### 3 YEAR STANDARD WARRANTY PERIOD

- The warranty period for your tool is 3 years from the date of purchase.
- The warranty period for batteries, battery packs and chargers is 1 year from the date of purchase.
- Calibrations are not covered under warranty as they are deemed wear and tear.
- All products have a standard warranty period, you do not have to register your products to obtain the standard warranty period.
- To claim under this warranty, the date of purchase of the tool must be documented by an invoice/ receipt.

#### 7 YEAR EXTENDED WARRANTY PERIOD

- The extended warranty is available on selected tools only.
- You may extend the warranty period for your tool to 7 years from the date of purchase. This excludes batteries, battery packs and chargers.
- Calibrations are not covered under warranty as they are deemed wear and tear.
- To obtain the extended warranty, the registration process must be completed within 30 days from the date of purchase.
- Failure to register your product online and/or submission of a valid invoice/receipt will void the warranty extension.
- Please ensure ALL information submitted/ uploaded is correct.
- Extended warranty is ONLY available via online registration, offline (mailing in of warranty registration) will not be accepted.

# **WARRANTY** (continued)

#### **AUSTRALIA**

"Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure."

For more information please visit consumerlaw.gov.au

#### **NEW ZEALAND**

For more information please visit consumerprotection.govt.nz

# **CUSTOMER SUPPORT**

To assist you with any queries or technical questions please contact customer support

Australia: 1300 658 338 New Zealand: 0800 367 527 United Kingdom: 0808 189 1152

# **SPECIFICATIONS**

Specifications	Lasertec 3DR ULTRA
Product code	91245
Warranty	7 Years*
Accuracy	±1.5mm at 10m
Operating range	60m (with detector)
Levelling range	±4°
Laser class	2 Red
Battery life	10 hours
Battery type	Li-ion battery pack (12V, 2600mAh, 19.24Wh) / 4x 1.5V AA
Vertical lines	2
Horizontal lines	1
IP rating	54
Weight (kg)	0.8 (inc. batteries)
Dimensions (mm)	150 x 187 x 128

<sup>\*</sup>With online registration (3 years without registration). Please refer to page 21 for details.

NOTES			

NOTES (continued)		

NOTES (continued)			



www.spoton.com.au